



Anleitung Offenstall/Weideunterstand

Die Rahmenteile aus der Platte schneiden, miteinander verkleben, ausrichten und gut trocknen lassen. Die Dachbalken aufkleben. Eine Lasur vor der Montage aufbringen. Gut trocknen lassen und die Teile durch Pressen wieder in Form bringen. Zuerst die Seitenteile aufkleben. Dann die Rückseite in die Dachbalken einfügen und verkleben. Zuletzt das Wellblechdach aufkleben. (Schutzfolie abziehen, die Folie ist selbstklebend.) Bei Bedarf kann das braune Kartondach unter die Folie geklebt werden.

Instructions open barn/pasture shelter

Cut the frame parts out of the sheet, glue them together, align them and let them dry thoroughly. Glue on the roof beams. Apply a glaze before assembly. Allow to dry thoroughly and press the parts back into shape. Glue on the side panels first. Then insert and glue the back into the roof beams. Finally glue the corrugated iron roof on. (Peel off the protective film, the film is self-adhesive.) If necessary, the brown cardboard roof can be glued under the foil.